

ANCHORING SUGGESTIONS FOR YOUR VISSCHER STRUCTURE


ANCHORING YOUR STRUCTURE TO A FIRM PLATFORM IS ONE WAY TO PREVENT DAMAGE CAUSED BY ENVIRONMENTAL FACTORS SUCH AS HIGH WINDS. PLEASE CONSIDER THESE ANCHORING SUGGESTIONS FOR CONCRETE AND WOOD PLATFORMS.

AS EACH ANCHORING PLATFORM IS DIFFERENT, VISSCHER SPECIALTY PRODUCTS WILL NOT BE HELD RESPONSIBLE FOR DAMAGES CAUSED BY THIRD-PARTY ANCHORING PRODUCTS AS SUGGESTED IN THIS INFORMATION PACKAGE.


PLEASE CONSIDER THESE SUGGESTIONS IN UNDERSTANDING THE END-CUSTOMER IS ULTIMATELY RESPONSIBLE FOR THE PURCHASE AND INSTALLATION OF ANY AND ALL ANCHORING HARDWARES.

FULLY ENCLOSED MODELS - SUGGESTED HARDWARE (NOT PROVIDED)


16X
SIMPSON STRONG-TIE
(SST)A33




WOOD PLATFORM

128X  1 1/2" #9 SIMPSON STRONG (SST) TIE EXTERIOR GRADE STRUCTURAL SCREW


CONCRETE PLATFORM

64X  1 1/2" #9 SIMPSON STRONG TIE (SST) EXTERIOR GRADE STRUCTURAL SCREW


64X  3/16 x 1 3/4" HEX HEAD TAPCON CONCRETE ANCHOR

OPEN AIR MODELS - SUGGESTED HARDWARE (NOT PROVIDED)


8X
SIMPSON STRONG-TIE
(SST)A33




WOOD PLATFORM

64X  1 1/2" #9 SIMPSON STRONG (SST)TIE EXTERIOR GRADE STRUCTURAL SCREW

CONCRETE PLATFORM

32X  1 1/2" #9 SIMPSON STRONG (SST)TIE EXTERIOR GRADE STRUCTURAL SCREW

32X  3/16 x 1 3/4" HEX HEAD TAPCON CONCRETE ANCHOR



- ① PLACE 'L' BRACKETS AGAINST THE PANEL UPRIGHTS AT THE LOCATIONS SHOWN.
- ② FASTEN THE 'L' BRACKETS TO THE PANEL UPRIGHTS USING FOUR (SST) #9 1 1/2" EXTERIOR GRADE STRUCTURAL SCREWS PER BRACKET.

CONCRETE PLATFORM


- ③a FASTEN THE 'L' BRACKET TO THE GROUND USING FOUR 3/16 X 1 3/4" HEX HEAD TAPCON CONCRETE ANCHOR TO SECURE THE PANELS TO THE CONCRETE BASE.

WOOD PLATFORM


- ③b FASTEN THE 'L' BRACKET TO THE GROUND USING FOUR (SST) #9 1 1/2" EXTERIOR GRADE STRUCTURAL SCREWS TO SECURE THE PANELS TO THE WOOD BASE.



Plan View of Enclosed Panels



- ① PLACE 'L' BRACKET AGAINST THE POSTS AT THE LOCATIONS SHOWN.
- ② FASTEN THE 'L' BRACKET TO THE POSTS USING FOUR (SST) #9 1 1/2" EXTERIOR GRADE STRUCTURAL SCREWS PER BRACKET.
- ③a **CONCRETE PLATFORM**
FASTEN THE 'L' BRACKET TO THE GROUND USING FOUR 3/16 X 1 3/4" HEX HEAD TAPCON CONCRETE ANCHOR TO SECURE THE PANELS TO THE CONCRETE BASE.
- ③b **WOOD PLATFORM**
FASTEN THE 'L' BRACKET TO THE GROUND USING FOUR (SST) #9 1 1/2" EXTERIOR GRADE STRUCTURAL SCREWS TO SECURE THE PANELS TO THE WOOD BASE.



Plan View of Open Air Gazebo

